




Lineset Schedule

41	PVC Cylc	30'-10"
40	Upstage Black	28'-1"
39	Unused	27'-7"
38	Unused	27'-1"
37	4th (C/O) Electric	26'-1"
36	Black Scrim	25'-6"
35	Legs #3	25'-0"
34	Border #3	24'-6"
33	Unused	24'-0"
32	Unused	23'-6"
31	Unused	23'-0"
30	Unused	22'-6"
29	Unused	21'-2"
28	Unused	20'-8"
27	Unused	20'-2"
26	Unused	19'-7"
25	3rd Electric	18'-9"
24	Unused	17'-5"
23	Legs #2	16'-11"
22	Border #2	16'-5"
21	Movie Screen	16'-0"
20	Midstage Black	15'-0"
19	Unused	12'-7"
18	Unused	12'-1"
17	Unused	12'-7"
16	*Hts LK2	12'-1"
15	2nd Electric	11'-1"
14	*Hts LK2	10'-3"
13	Unused	9'-9"
12	Unused	9'-3"
11	Legs #1	8'-9"
10	Border #1	8'-3"
9	Unused	7'-9"
8	Unused	7'-3"
7	#1A Electric	5'-11"
6	Overhead Mic	4'-5"
5	1st Electric	3'-7"
4	Jib/SL Button Only	2'-11"
3	Movie Screen	1'-11"
2	Main Drape	1'-5"
1	Grand Balance	0'-11"



CL